PARTS LIST

for

Whirlpool CORPORATION

27" ELECTRIC BUILT-IN MICROWAVE OVEN COMBINATION SELF-CLEAN OVEN

MODEL RM778PXT-5

Panoramic

FOR CUSTOMER SATISFACTION ALWAYS USE
FACTORY SPECIFICATION PARTS

Whirlpool CORPORATION
Benton Harbor, Michigan.

© 1993 WHIRLPOOL CORPORATION

7-93 Litho in U.S.A.

Part No. 816730

7/93

CONTROL PANEL AND LATCH PARTS

For Model: RM778PXT-5



2	877884	Axle, Latch
3	816384	Latch, Door
4	816289	Motor, Latch Assembly
	241428	Screw, 10-24 x 1/2 (3)
5	816454	Switch, Latch (2)
6	816331	Trim, Control Panel
7	816282	Plate, Motor Mounting
	241428	Screw, 10-24 x 1/2 (2)
8	816275	Housing, Control
	241428	Screw, 10-24 x 1/2 (2)
	308685	Screw, 10-24 x 1/2 (5)
9	816288	Rod, Latch
10	816335	Cover, Housing
11	241212	Terminal Block
	9426223	Screw, 10-16 x 1 (2)
12	877614	Housing, Latch
13	816276	Cover, Latch
14	816374	Bracket, Trim Mounting
24	816309	Bracket, Control
	241428	Screw, 10-24 x 1/2 (4)
25	816413	Thermostat, Oven
	877919	Screw, 8-32 x 3/16 (2)
26	816445	Switch, Oven Light
27	816313	Switch, Oven Selector
	877919	Screw, 8-32 x 3/16 (2)
28	816316	Indicator Light (Clean)
	816315	Indicator Light (2) (Lock, Oven)
32	816269	Panel, Glass (Control)
33	816322	Trim, Vent
	241428	Screw, 10-24 x 1/2 (4)
34	816346	Trim, Top
	487010	Screw, 6-32 x 1/2 (4)
36	816332	Bezel, Switch
38	310834	Knob, Control (2)
39	868363	Bumper (6)
46	311068	Escutcheon, Selector Switch
	877919	Screw, 8-32 x 3/16
47	816405	Escutcheon,
	877919	Screw, 8-32 x 3/16

DOOR PARTS

For Model: RM778PXT-5



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

919-A-14 (CONTINUED ON 919-B-1)

1	816506	Frame, Oven Door
	816511	Screw, #10 x 3/8 (5)
2	816438	Handle, Oven Door
	816359	Screw, 10-24 x 2 (2)
3	816356	Glass, Outer
4	816441	Insulation, Oven Door
5	816508	Panel, Airwash
6	816513	Glass, Inner
7	816512	Spacer, Glass
8	816507	Liner, Oven Door
	816270	Screw, 10-24 x 5/8
9	816510	Baffle, Weldment
	816362	Screw, 10-24 x 2 3/4 (4)
10	816446	Seal, Oven Door
12	816363	Seal, Window
13	816385	Hinge Assy. (2)
	816270	Screw, 10-24 x 5/8 (4)
14	816720	Spacer, Door Handle (2)
15	816509	Collar, Glass
16	816440	Spacer, Handle
19	877507	Strike
	816270	Screw, 10-24 x 5/8 (2)
20	816505	Button, Door Spacer

LOWER OVEN PARTS

For Model: RM778PXT-5



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	816403	Oven (27" Pyro)
3	877803	Receptacle, Light
4	816389	Bulb, Light
5	877804	Lens, Light
6	816291	Retainer, Lens
7	816379	Retainer, Door
8	816321	Switch, Oven Light
9	816295	Unit, Broil
	241428	Screw, 10-24 x 1/2 (2)
10	816297	Support, Broil Unit
	241428	Screw, 10-24 x 1/2 (2)
11	816293	Unit, Bake
	241428	Screw, 10-24 x 1/2 (2)
12	816344	Trim, Base
	3149333	Screw, 10-16 x 1/2 (2)
13		Side Trim (Inner)
	816271	R.H.
	816305	L.H.
	308685	Screw, 10-24 x 1/2 (10)
14	816442	Vent Tube
15	816277	Insulation Retainer, Top and Side
16	816449	Casing, Top
17	816278	Retainer, Insulation Bottom
	241428	Screw, 10-24 x 1/2 (4)
18	816279	Casing, Back and Sides
	308685	Screw, 10-24 x 1/2 (14)
19	816283	Casing, Bottom
20	816284	Support, Height
	308685	Screw, 10-24 x 1/2 (12)
21	816287	Spring, Oven (2)
	241428	Screw, 10-24 x 1/2 (2)
22	816317	Side Trim, Outer (2)
	3149333	Screw, 10-16 x 1/2 (4)
26	816386	Front Frame
	816270	Screw, 10-24 x 5/8 (6)
27	816319	Cover, Motor
	241428	Screw, 10-24 x 1/2 (2)
28	816387	Spacer, Oven
29	816388	Channel Assembly, Hinge (2)
30	816378	Cover, Rear
	241428	Screw, 10-24 x 1/2 (8)
31	816333	End Cap, Top
34	816342	Rack, Oven Regular
35	816343	Rack, Oven Offset
36	816448	Grill, Broiler Pan
37	816437	Pan, Broiler
38	816414	Cover Plate
39	816329	Retainer
40	816328	Insulation

MICROWAVE MOUNTING PARTS

For Model: RM778PXT-5



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	816347	Extrusion, Bottom
2	816348	Extrusion, Side (2)
3	816349	Extrusion, Top
4	816327	Elbow, Vent
5	816369	Tube, Vent
6	816375	Channel, Slide (2)
7	816394	Retainer, Microwave
8	816390	Support, Bottom (2)
9	816398	Channel, Slide (2)
10	816298	Oven Vent
11	816300	Bracket, Vent Tube
12	816395	Power Relay
13	816391	Casing, Back and Sides
14	816392	Casing, Bottom
15	816393	Duct, Air
16	816301	Duct, Air

MAGNETRON AND AIR FLOW PARTS

For Model: RM778PXT-5



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	3147853	Transformer
4	312185	Screw, 10-32 x 1/2 Hex Washer W/Ground Ring (10)
5	312619	Bracket, Capacitor
8	661004	Capacitor
	312631	(Alt.)
	312632	(Alt.)
11	314121	Fuseblock
15	313830	Rectifier, High Voltage
16	312713	Screw, 8-32 x 3/8
22	309796	Fuse (20 Amp)
23	313578	Air Duct (Horizontal)
26	660595	Magnetron
	311992	(Alt.)
	311993	(Alt.)
	311994	(Alt.)
	311995	(Alt.)
	313034	(Alt.)
28	661165	Thermal Protector
	312800	(Alt.)
	313521	(Alt.)
29	312782	Screw, 6A x 3/8 (2)
34	346893	Screw, 11-16 x 1/2 Double Load Space Thread (5)
36	313641	Transmotor
37	311922	Pulley, Motor
39	311999	"E" Ring (2)
40	313601	Bracket, Motor
42	311865	Screw, 6 x 8/32 Round Head Cross Recess (4)
43	3147223	Wheel, Blower
44	313130	Jumper, High Voltage Red (6-5/16")
45	309330	Cable Tie (2)
46	3147863	High Voltage Lead, Gray 6-3/4" (2)
47	311311	Clip
48	3147262	Air Duct
49	346893	Screw, 11-16 x 1/2

CABINET AND STIRRER PARTS

For Model: RM778PXT-5



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	3147004	Cover, Side
	313638	Screw, 8-18 x .50 (4)
3	313735	Plate, Tuning
4	313739	Support (4)
5	3149314	Grill, Air
6	313855	Thermal Fuse (Includes Illus. 7)
7	312713	Screw, 8-32 x 3/8 Pan Head Phillips
8	312023	Bushing, Stirrer
9	3147378	Nut (4)
10	312026	Shaft, Stirrer
11	313595	Stirrer Blade
12	312025	Washer, Nylon
14	311923	Pulley, Stirrer Blade
15	311999	"E" Ring
17	311721	Nut, Standard Hex 1/4-20
18	313646	Belt, Drive
20	313563	Stirrer Cover
21	313740	Fastener (4)
22	313816	Screw, 8-32 x 1/2 (3)
38	3148557	Probe Jack
39	313105	Washer, Internal Lock
41	313104	Nut
43	816400	Probe,

CONTROL PANEL PARTS



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

816730

919-8-8

1	3150203	Frame, Control Panel
2	3148258	Microcomputer
3	313818	Screw, 8-32 x 3/16 (6)

DOOR AND LATCH PARTS

For Model: RM778PXT-5



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	311354	Bracket, Catch
	312713	Screw 8-32 x 3/8
2	311795	Catch (2)
3	661144	Switch
	313075	(Alt.)
	313123	(Alt.)
4	661146	Switch, Primary & Secondary Interlock (2)
	313077	(Alt.)
	313125	(Alt.)
5	312717	Screw, 4-40 x 3/4 Pan Head Thread Form (4)
6	661145	Switch, Light Monitor
	313076	(Alt.)
	313124	(Alt.)
7	313126	Insulator
8	310211	Screw, 4-40 x 10 (2)
9	309080	Screw, 8-32 x 3/8 Slot Hex Washer Head Self-Tapping (Ground)
10	311360	Shield
11	313740	Fastener (2)
12	311928	Rivet, Pop (3)
13	313120	Switch, Miniature
19	3172228	Frame, Door
20	3171012	Door, Inner
22	311777	Screw, 8-32 x 19/32 Torx Truss Head (6)
30	329066	Latch Assembly
31	311352	Spring, Torsion (2)
	313811	Screw, 8-32 x 5/16
32	314169	Handle, Door
33	314168	Button, Door Handle
34	310197	Spring, Compression
35	313820	Screw, (2)
37	311722	Screw, 8-32 x 7/16
38	3148297	End Cap
40	313823	Screw, 8-22 (4)

WIRING HARNESS PARTS

For Model: RM778PXT-5





FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	3147072	Harness, Wiring (Main)
2	3148057	Harness, Wiring (Control)
3	314150	Plug, Terminal
4	311575	Block, Disconnect
5	308565	Connector
6	312795	Terminal
7	310241	Housing, Plug
10	248562	Terminal
11	309330	Tie Cable

SPLICING WIRES-25 FT. LENGTH

242828	Wire, Black 12 Ga. 150~c
242820	Wire, Black 14 Ga. 150~c
242821	Wire, Blue 14 Ga. 150~c
242822	Wire, Brown 14 Ga. 150~c
242830	Wire, Brown 14 Ga. 200~c
242823	Wire, Green 14 Ga. 150~c
242824	Wire, Orange 14 Ga. 150~c
242829	Wire, Red 12 Ga. 150~c
242825	Wire, Red 14 Ga. 150~c
242831	Wire, Red 14 Ga. 200~c
242826	Wire, White 14 Ga. 150~c
242827	Wire, Yellow 14 Ga. 150~c
242832	Wire, Yellow 14 Ga. 200~c

PAINT, TOUCH-UP (1/2 oz.)

72032	Black
72017	White
72107	Almond
72110	Harvest Gold
72112	Toast
72113	Platinum
261869	Citrine White (Microwave)
254323	Touch-Up, Oven
511873	White Porcelain (2 Oz.)

PAINT, PRESSURIZED SPRAY (13 oz.)

206922	Primer, White
206925	Leveler, Enamel
261890	Harvest Gold
350956	Almond
285365	Toast
285366	Platinum
799339	Black
799343	White
261900	Citrine White (5 Oz.)

PAINT, BULK (1 qt.)

799340	Black (Uncut)
799344	White (Uncut)
261891	Harvest Gold (Uncut)
978883	Almond (Uncut)
285367	Toast (Uncut)
285368	Platinum (Uncut)

INSULATION

261514	Insulation, Fiberglass (1-1/2" x 24" x 120")
240132	Insulation, Fiberglass (2-1/2" x 22" x 120")

REFINISHING MATERIAL

261582	Grease
482338	Sealer, Silastic (3 Oz.)
591014	Adhesive, Loctite (1/3 Oz.)
309551	Line, Splice (5)
799832	Kit, Porcelain Repair (White)

ACCESSORY PARTS

242985	Rotisserie Kit
814023	Non-Vent Kit
832985	Rack, Cooking

LITERATURE PARTS

LIT816198	Installation Instructions
LIT816197	Use & Care Guide (Range)
LIT816196	Use & Care Guide (Microwave)
LIT311894	Cookbook (Microwave)
LIT313358	Cooking Guide
LIT816730	List, Repair Parts

CABINET PARTS

For Model: RM778PXT-5



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

919-B-13

1	313614	Trim, Shelf Front
2	313615	Trim, Shelf Rear
3	313639	Shelf, Microwave (Install with Silastic 307576)
4	330514	Socket
	312713	Screw, 8-32 x 3/8 (2)
5	313969	Bulb, Oven Light
6	313653	Support, Rack (4)
7	816401	Rack